JANOME 5300QDC



5300QDC

JANOME

5300QDC Features

300 built-in stitches, plus alphabet	Automatic thread cutter	Foot pressure dial with 6 levels
12 automatic sensor buttonholes	Workspace: width 170mm x height 110mm Machine: L406mm x H302mm x W170mm	LCD screen with enhanced information display and easy navigation touchpad
Maximum stitch width: 7mm	One-hand style needle threader	Opening side cover above needle area
Maximum stitch length: 5mm	Manual thread tension control	Detachable stitch chart
Programmable for up to 50 different combination patterns	Start/stop button, Stitch lock-off button, Reverse stitch button, Speed control slider	11 standard feet includes 1/4 inch seam foot and even feed foot with guide
Stitch mirroring	Twin needle button - set stitch for twin needle	Optic magnifiers in 3 strengths (20,40,60)
Clip-on presser feet	Speed control slider	White LED lighting
Memorised needle up/down setting	Stitch pattern editing	Large extension table
Monora nocale apracting	Other patient calling	Large extension table
Superior plus feed system™ (SFS+)	Drop feed	Knee lift

Innovative LCD Screen with Fast Navigation and Direct Stitch Selection

Intuitive navigation allows you to quickly locate your stitch choice and setting options using the 10 direct selection buttons. The unique LCD display shows stitch pattern image and mode as well as helpful sewing information.













Superior Plus Feed System

Only Janome machines have this super stable feeding system that moves your fabric in perfect synchronization with the needle and bobbin. A seven-piece feed dog works with a flat feed mechanism, which keeps the feed dogs parallel to the needle plate whether sewing forwards or backwards.

Foot Pressure Dial and Opening Face Plate

There are 6 levels of foot pressure available, for stitching the lightest of fabrics, to a heavy denim or a quilt sandwich. The face plate (side cover above the needle area) opens giving access to the threading path, if thread issues occur and for easy access to cleaning.

Fully Automatic Sensor Buttonholes

Drop your button into the sliding button holder and the foot makes the buttonhole, the right size every time. Choose from 12 styles including square, rounded, keyhole, heirloom, and welted.

Knee Lift

This machine has a knee lift function. The connection hole is located on the bottom right of the machine front. The knee lift is operated by your right leg when seated in front of the machine. Push the knee lift to the right and the sewing foot on the machine is raised, release the knee lift to lower the foot. This function is a time saver and easy to use.

JANOME

AUSTRALIA

Janome Australia Pty Ltd. PO Box 1383, Moorabbin 3189 Victoria www.ianome.com.au

NEW ZEALAND Janome New Zealand Ltd PO Box 447, Drury, Auckland 2247 www.janome.co.nz